



MIDI Implementation Chart

Model: **Expander DX1000/10**

Date: **10.3.08**

Version: **1.50**

FUNCTION		TRANSMITTED	RECOGNIZED	REMARKS
Basic Channel		X	1 - 16	Memorized
Default Channel		X	1 - 16	
Mode	Default	Mode 3	Mode 3	
	Messages	X	X	
	Altered	X	X	
Note Number		X	1-128	
True Voice			1-128	
Velocity	Note ON	X	O	
	Note OFF	X	O	
After Touch	Keys	X	X	
	Channels	X	O	
Pitch Bender		X	O	
Control Change		X	32 1 7 64 65 66 121	Bank Select 0 - 5 Mod. Wheel 2 Channel Volume Footswitch A Footswitch B Footswitch B Reset All Cntrls
Program Change		X	0 - 69	
True#			0 - 69	
System Exclusive		O	O	MIDI Dump
System Common	Song Pos.	X	X	
	Song Sel.	X	X	
	Tune	X	X	
System Real Time	Clock	X	X	Start, Stop
	Commands	X	X	
AUX Mes-sages	Local on/off	X	X	
	All Notes off	X	O	
	Active Sens.	X	O	
	Reset	X	X	
Notes				O : Yes X : NO

Mode 1: OMNI ON, POLY
Mode 3: OMNI OFF, POLY

Mode 2: OMNI ON, MONO
Mode 4: OMNI OFF, MONO